

# ECHO-MAGNETIC BUZZER

## 《PART NUMBERING SYSTEM》

B1 S 3 120 L( ) - 01

Flow number

01 : Standard type

02~99 : Variants

Remarks

Connect method

L : Lead

P : Pin

Rated voltage

120 : 12V

015 : 1.5V

030 : 3V

1200 : 120V

415 : 4~15V

932 : 9~32V

Frequency : 3×1KHz

Tone

S : Single

P : Pulse

D : Dual tone to be selected

T : Two

R : Siren

H : Hex Tone

PN: Pulse Slow

PF: Pulse Fast

Series